

# ${f DSPA6}$ OWER 'S MANUAL DSP CAR POWER AMPLIFIERS





- Please read this quick guide before using the product
- For detailed tuning operations and settings, please refer to the DSPA6 user manual on the website
- http://www.awaveaudio.com

$\triangle$	Warning
•	vvarining

This symbol indicates important instructions. Failure to pay attention may result in serious injury or death to persons.

#### If a problem occurs, stop using it immediately

Failure to do so may result in personal injury or damage to this product. Please return the product toto an authorised dealer or to the nearest service centre for repair.

### This product is only suitable for use in vehicles with a negative 12V ground

Failure to do so may cause a fire or other accident.

#### Wiring and installation by professionals

Wiring and installation of this product requires specialist skills and experience. For safety reasons, please contact the dealer from whom you purchased the product for installation.

#### Do not disassemble or modify

Failure to do so may result in an accident, fire orelectric shock.

### Small objects such as bolts or screws should be kept out of the reach of children

Swallowing small objects can lead to serious injury. If swallowed, seek immediate medical attention.

### Do not use any function that will distract you while driving

Any function that interferes with your concentration should only be used when the car is fully stopped. If you wish to use these functions, park the vehicle in a safe place first. Failure to do so may result in an accident.

# It is important to keep the volume at a level whereyou can still hear the noise outside the vehicle while driving.

Not being able to hear emergency vehicle sirens and road warnings (train crossings etc.) is very dangerous and can lead to accidents. In addition, excessive noiselevels can lead to hearing damage.



### Note

This symbol indicates important instructions. Failure to pay attention may result in serious injury or death to persons.

#### **Product cleaning**

Please use a dry, soft cloth to clean the product regularly. If stains are difficult to remove, please use water to wet the soft cloth. Other electronics cleaners can also be used.

#### Temperature

Make sure the temperature in the car is between +60 and -20°C before switching on the machine.

#### Repairs

If you encounter a problem, do not repair it yourself. Please take the product to your authorized dealer or a nearby service centre for repair.

#### Installation Location


The machine must not be installed in any of the following locations.

- near direct sunlight and heat sources
- Areas with high humidity and near water sources
- Dusty places
- places subject to severe vibrations


<sup>\*</sup>Disposal of electronic products should be through proper recycling channels to reduce e-waste pollution.

# **Machine Introduction**

**Dimension Installation instruction** 







<sup>\*</sup>The machine has built-in Bluetooth

# **Machine Introduction**

Introduction to machine interfaces and functions

### 1 USB 2.0 port

It can be connected to a PC via USB 2.0 cable for detailed tuning operations and settings.

- (2) System extension interface
- (3) Bluetooth
- (4) RCA audio output connector
- 3 sets of RCA audio signal outputs for
- (4) connection to external amplifiers.

(5) RCA audio input connector

2 sets of RCA audio signal inputs, can be connected to the RCA audio signal output of the car CD/DVD player.

- 6 Power indicator
- (7) Input selector switch

When the switch is set to "ACC", the machine is started by ACC; when the switch is set to AUTO, the machine is started by the high level input signal FL-/FL+.

### 8 High level input/output and power supply interface

The high level input is connected to the regular output of the car CD/DVD and the high level output is connected to the speakers.

Speaker Output			High Level Input				Powerin		
+RR	-RR	+RL	-RL	-FR	-FL	-RL	-RR	GND	+12V
+FL	-FL	+FR	-FR	+FR	+FL	+RL	+RR	OUT	IN

### 9 Car CD/DVD player

### (10) External amplifier

### Accessory list

The following accessories should be included in the DSPA6 box. If any are missing, please contact an authorised dealer.

Accessories	Quantity			
USB 2.0 cable	1 unit			
Fixing bracket	4 pcs			
Instruction manual	2 books			

# **Specification**

Dynamic range	≤100dB
Signal to Noise (RCA)	≥100dB
Total ramp distortion	≤0.01%
Input Voltage	High level:32Vpp; RCA: 6Vpp
Output voltage	High level:28Vpp; RCA: 8Vpp
Power rating	4CHx35W(4Ω,14.4V, 1kHz, 10%THD)
Maximum power	4CHX50W(4Ω,14.4V, 1kHz, 10%THD)
Input/output sensitivity (RCA)	1:1.3 (without power amplification)
Frequency Response	20Hz~20KHz
System sample rate	48kHz/24bit
Input Impedance	High level:10Ω; RCA:47kΩ,
Output impedance	51Ω
Operating voltage	9~16V
Standby power	≤0.1W
REM start input	ACC or High level: (FL-/FL+)
REM start output	3~16V
Start-up time	5S
Operating ambient temperature	-20~60°C
Storage temperature	-40~85°C
Net weight	0.8kg
Size	174mmX121.2mmX42mm

### **Specification**

Input signal	4-channel high level, 4-channel RCA universal, HD Bluetooth				
Output signal	4-channel high level, 6-channel RCA audi				
Output signal gain	Range : Mute, -40dB to +12dB				
	Type : Parametric equalisation, graphical equalisation				
Output signal equaliser	Frequency: 20Hz to 20kHz, resolution 1Hz				
	Q-value (slope or gradient) : 0.3 to 15				
	Gain: -15dB to +15dB, resolution 0.1dB				
	Multiple independent high and low pass filters for each output channel.				
	Filter type: Nink-Rein, Bessel, Butterworth				
Output signal divider	Filter crossover point: 20Hz to 20kHz, resolution 1Hz				
	Filter slope (slope): 6dB/Oct to 48dB/Oct				
Output phase	Positive or negative phase (+/-)				
Output Delay	0.000~10ms				
Preset sound	Machine can save up to 8 sets of pre-programmed sound data				

# Harmful substance composition

Name and content of harmful substances or elements in the product.

Component	Harmful substance or element					
name	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Circuit board components	Х	0	0	0	0	0
Housing components	0	0	0	0	0	0
Display components×	Х	0	0	0	0	0
Accessories ×	Х	0	0	0	0	0

This form has been prepared in accordance with the provisions of SJ/T 11364

- O: means that the content of the hazardous substance in all homogeneous materials of the component is below the limit specified in GB/T 26572.
- X: means that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit specified in GB/T 26572. Components marked with an "x" have been found to exceed the limit because there is currently no proven alternative technology available to the industry.

### **Repair Station Information**

- •For inquiries regarding repairs, please refer to the "Repair Station Information" below.
- •The name, telephone number and address of the repair station are subject to change.

No	Repair Station	Address	Contact person	Phone number
01	Guangzhou, China	No.102, 1F, Block 16, North Zone, Hesbian Tongda Business Park,Baiyun District, Guangzhou,China	After Sales	19866009958